

Pump Sys Instructions:

1. Open 1, 3, 4 crane, put water in the right pipe. Close 4, fill. Close 1.
2. Close 3, open 1, 2 - fill left pipe. Close 1.
3. Close 2, open 4, switch on the pump.
4. Open 3, open 2. Close 4. If press - open 4. Fill the water tank.
5. Open 4, close 2, open 1, close 4. End of work.
6. Switch off the pump, close 1, open 2, 3, 4, 5. Close 5 after water reducing.